



SELECTED ACCESSORIES

1.	BY-PASS ARRANGEMENT
2.	SPUR GEAR ARRANGEMENT
3.	ELECTRICAL ACTUATOR
4.	CHANNEL AND SHOE ARRANGEMENT
5.	EXTENSION SHAFTING/HEAD STOCK / BEVEL GEAR ARRANGEMENT
6.	THRUST BALL BEARING ARRANGEMENT
7.	LEVEL POSITION INDICATOR
8.	AIR RELIEF PLUG
9.	DRAIN PLUG
10.	BACK BUSH/BUSHING ARRANGEMENT
11.	LOCKING ARRANGEMENT